



Bosch ETB Clamp Adapter
Part #900012-S/B & 900014-S/B

WARNING! Please read the whole guide before installing this part.

Legals:

This part is sold with a LIMITED warranty that only covers defects in manufacturing. This warranty does not cover any damage incurred by using this part. The installation of this part may also void any vehicle warranties.

After opening the packaging please check to see if any parts are missing or damaged. If something is missing or damaged please contact us immediately. Do not install the product.

Do not modify this part in any way. Modifying the part may result in failure of the part and voids all possible warranties.

Installation Guide

Install the thin o-ring/s onto the Bosch throttle body groove as shown below. The 82mm adapters use 2 o-rings and the 74mm adapter only uses 1 o-ring.



Apply a small amount of lubricant to the o-rings and slide the adapter onto the throttle body. Align the mounting holes on the adapter to the mounting holes on the throttle body.



Place the spacers in between the adapter and throttle body, insert the M6 bolts through.



Lastly, install the thick o-ring into the o-ring groove on the adapter. The throttle body is now ready to be installed.



And that's it... Thank you for supporting TAARKS.