



Fuel Pulse Damper

WARNING! Please read the whole guide before installing this part.

Legals:


TAARKS fuel pulse dampers have been designed and are intended for off-road use only. The installation of this part on a vehicle intended for use on public roads may violate laws and regulations in your country/state. Additionally, this part is sold with a LIMITED warranty that only covers defects in manufacturing. This warranty does not cover any damage incurred by using this part. The installation of this part may also void any vehicle warranties. Refer to a performance specialist for proper installation.

After opening the packaging please check to see if any parts are missing or damaged. If something is missing or damaged please contact us immediately. Do not install the product.

Do not modify this part in any way. Modifying the part may result in failure of the part and voids all possible warranties.

Installation Guide

Remove the circlip from the damper body with a pair of circlip pliers.



Remove the white plastic ring from the fuel pulse damper.



Install the supplier o-ring onto the fuel pulse damper.



Lubricate the o-ring and install the damper into the housing.



While pressing the damper down install the circlip into the circlip groove.



And that's it... You're all done. Enjoy & thank you for supporting TAARKS.